



NOTES:

1. SEE SPECIFICATIONS FOR PLANTING SOIL REQUIREMENTS.
2. SHRUBS SPECIFIED AS BARE ROOT (B.R.) SHALL BE KEPT MOIST; ENSURE THAT ROOTS ARE PLACED NATURALLY, WITH SOIL MIX BACKFILLED CAREFULLY TO PREVENT ROOT DAMAGE.
3. PROVIDE 100 HIGH EARTH SAUCER AROUND SHRUB BED WITH 100 WIDE SMOOTH BED EDGE TO RETAIN MULCH.
4. REMOVE SHRUB POT AND SCARIFY ROOT BALL BEFORE PLANTING.
5. ALL MEASUREMENTS ARE IN MILLIMETRES UNLESS STATED OTHERWISE.



**PLANNING,
DESIGN &
DEVELOPMENT
DEPARTMENT**

TITLE: MULTI-STEM SHRUB AND MASS SHRUB PLANTING

DRAWING NO. PDD 912

REVIEWED BY: *SJ Dawson*

SCALE: N.T.S.

APPROVED BY: *Steve Walsh*

DATE: JANUARY 2007