



- NOTES:**
1. SEE SPECIFICATIONS FOR TOPSOIL REQUIREMENTS.
  2. THE TREE PIT IS TO HAVE A 300MM CLEAR PERIMETER BETWEEN ROOTBALL AND SCARIFIED EDGE.
  3. REMOVE TREE WRAP PRIOR TO INSPECTION BY CITY OF BRAMPTON REPRESENTATIVE.
  4. CALIPER TO BE MEASURED 1400 MM (1.4 M) ABOVE FINISH GRADE.
  5. THE USE OF AUGERS OR TREE SPADES FOR EXCAVATING TREE PITS IS NOT PERMITTED.
  6. SCARIFY SUBGRADE OF PLANTING PIT TO PROPER DEPTH.
  7. ALL MEASUREMENTS ARE IN MILLIMETRES UNLESS STATED OTHERWISE.

- PRUNE ONLY DEAD OR DAMAGED BRANCHES IN ACCORDANCE WITH PROPER HORTICULTURAL PRACTICES. DO NOT PRUNE LEADER.
- TREE TIE MATERIAL. (SEE SPECIFICATIONS)
- TWO 50 MM DIA. WOOD STAKES, IMMEDIATELY AFTER PLANTING . DRIVEN BESIDE AND BELOW ROOT BALL INTO EXISTING UNDISTURBED SOIL.
- TRUNK RODENT PROTECTION.
- PLANT TREES 100 MM HIGHER THAN FINISH GRADE.
- 100 MM DEPTH MULCH AS PER SPECIFICATION, 75 MM AWAY FROM AROUND PLANT TRUNK
- PROVIDE 150 MM HIGH SAUCER RIM.
- CUT AND REMOVE TOP RING OF WIRE BASKET AND TOP THIRD OF BURLAP FROM ROOT BALL . REMOVE ALL TIES FROM PLANT.
- TOPSOIL. (SEE SPECIFICATIONS)
- COMPACTED TOPSOIL UNDER & BESIDE ROOT BALL TO PREVENT SOIL SETTLEMENT.
- EXISTING UNDISTURBED SOIL.