



PRECAST CONCRETE UNIT PAVERS: REFER TO MANUFACTURER'S RECOMMENDATIONS FOR INSTALLATION AND SEALING; REFER TO THE PLANS AND SPECIFICATIONS FOR PATTERN, PAVER TYPE, AND COLOUR AND PAVER DIMENSIONS.

BRUSH CLEAN SHARP SAND INTO JOINTS

30 mm LEVELLING BED OF COARSE SAND

SOD ON 100mm TOPSOIL

CONCRETE EDGE RESTRAINT, 30MPA SAWCUT 3600mm O.C.

SUBGRADE, COMPACTED TO 98% SPD

150 mm MINIMUM DEPTH OF 19 mm CRUSHER RUN COMPACTED TO 98% S.P.D.

#### WORKMANSHIP

PAVERS SHALL BE INSTALLED IN STRICT ACCORDANCE WITH THE MANUFACTURER'S RECOMMENDATIONS WITH TIGHT BUTT JOINTS OF APPROXIMATELY 3 mm, ON A SAND BASE. SAW CUT PAVERS AS REQUIRED. USE AN APPROVED VIBRATORY COMPACTOR IN A CIRCULAR PATTERN. SPRINKLE SAND OVER AREA TO PREVENT CHIPPING FOR HEAVIER VIBRATORY COMPACTION. ALL DAMAGED OR CHIPPED PAVERS MUST BE REPLACED AT THE CONTRACTOR'S COST. BRUSH SAND INTO JOINTS AND SPRINKLE WITH WATER UNTIL JOINTS ARE FILLED.

#### EDGE RESTRAINT

REFER TO SPECIFICATIONS. EDGE RESTRAINT MUST BE APPROVED BY LANDSCAPE ARCHITECT PRIOR TO COMMENCING WORK.

#### PREPARATION

EXCAVATE AND REMOVE ALL TOPSOIL AND UNSTABLE MATERIALS OFF SITE. SUBGRADE TO BE GRADED TO SIMILAR CONTOURS AS FINISH GRADE. COMPACT SUBGRADE TO 95% SPD. PLACE 150 mm LAYER OF 19 mm CRUSHER RUN LIMESTONE. COMPACT TO 98 % SPD.

PLACE MAXIMUM 30 mm UNCOMPACTED SAND FOR LEVELLING COURSE.



PLANNING,  
DESIGN &  
DEVELOPMENT  
DEPARTMENT

TITLE:  
**PRECAST CONCRETE UNIT PAVING  
FOR PATHWAYS (LIGHT DUTY)**

DRAWING NO.  
PDD **518**

REVIEWED BY: *[Signature]*

SCALE: N.T.S.

APPROVED BY: *[Signature]*

DATE: JANUARY 2007